

**select tabouret bar 11-370**

Werner Max Moser, 1934

Sitz Formsperrholz, Sitzrahmen und Füsse aus gebogenem Massivholz, Fussring Stahlrohr verchromt  
B39, H80

Werner Max Moser, 1934

Assise rembourrée, cadre du siège et pieds en bois massif cintré, repose-pieds en acier chromé.  
L39, H80

Werner Max Moser, 1934

Moulded plywood seat, seat frame and legs of solid bentwood, chrome-plated connection ring  
W39, H80


Varianten / variantes / variants



select  
11-373

Technische Angaben / specifications / specifications

Masse / mesure / measure



Gewicht / ponds / weight

3.7 kg 7.4 lb

**select tabouret bar 11-370**

Holzarten / types de bois / types of wood

Belag / revêtement / surface



Hêtre naturel      BN 000 AM  
Buche natur      BN 000 AM  
Beech natural    BN 000 AM



Hêtre noir            BB 203 SG  
Buche schwarz      BB 203 SG  
Beech black        BB 203 SG



Chêne naturel      EN 000 AM  
Eiche natur        EN 000 AM  
Oak natural        EN 000 AM




Hêtre anthracite    BB 200 SG  
Buche anthrazit    BB 200 SG  
Beech anthracite   BB 200 SG




Hêtre teinté blanc    BG 172 SG  
Buche geweisst    BG 172 SG  
Beech whitewashed BG 172 SG



Chêne chêne fumée    EB 535 AM  
Eiche Räuchereiche    EB 535 AM  
Oak smoked oak        EB 535 AM



Hêtre teinté ebony    BB 100 SG  
Buche Ebony        BB 100 SG  
Beech ebony        BB 100 SG



Hêtre teinté noyer    BB 151 SG  
Buche Nuss            BB 151 SG  
Beech walnut        BB 151 SG